

UNIVERSAL SOFTWARE LOCK SETUP

The Universal Lock may be set up in either of two modes:
OEM 2-User Mode (Option A) OR Standard 1 or 2 User Mode (Option B)
The mode described in the following pages is Option B
Full details on Option A can be found in UR40-20 OEM Instructions
At www.QSecurityIndustries.com/ Resources

ALL functions are to be performed with door open and bolts thrown to locked position!
Factory default code is 5-5-5-5-5-5

Option A - To activate Primary/Service code and Secondary/User code in one step:

- a) Press and hold [0] key until double beep and keypad LED stays on
- b) Enter a 6-digit Primary/Service code (do NOT use 1-2-3-4-5-6 as Service code)
- c) Re-enter new 6-digit code to confirm, double beep and LED goes out
- d) Primary/Service code is now active and can open the lock
- e) Secondary/User default code 1-2-3-4-5-6 is also active, can open the lock, and should be changed by end user

Option B - To activate Primary code without installing Secondary code:

- a) Press and hold [0] key until double beep and keypad LED stays on
- b) Enter 1-2-3-4-5-6 as Primary code
- c) Re-enter 1-2-3-4-5-6 to confirm Primary code
- d) Primary code is now active, can open the lock and should be changed by end user

Operations

To open

- a) Enter a 6-digit code (Primary or Secondary), double beep = valid, long beep = invalid

To change code

- a) Press and hold [0] key until double beep and keypad LED stays on
- b) Enter current code to be changed (Primary or Secondary)
- c) Enter new 6-digit code
- d) Re-enter new 6-digit code to confirm, double beep and LED goes out

To install/replace Secondary code

- a) Press and hold [1] key until double beep and keypad LED stays on
- b) Enter current Primary code
- c) Enter new 6-digit Secondary code
- d) Re-enter new 6-digit Secondary code to confirm, double beep and LED goes out
- e) Old Secondary code is deleted and replaced with the new one

To delete Secondary code (available only if **Option B** selected)

- a) Press and hold [3] key until double beep and keypad LED stays on
- b) Enter Primary code, user code is now deleted

To setup time delay (available only if **Option B** selected)

- a) Press and hold key [9] key until double beep and keypad LED stays on
- b) Enter Primary code
- c) Enter time delay and open window values in minutes
(i.e. 0305 = 3 minute delay and 5 minute open window)
- d) Re-enter time delay and open window values to confirm, double beep and LED goes out

Factory reset

- a) Press and hold [0] until double beep and keypad LED stays on
- b) Enter current Primary code
- c) Enter 5-5-5-5-5-5
- d) Re-enter 5-5-5-5-5-5 to confirm, double beep and LED goes out
- e) Lock is now reset to Factory mode and may be programmed for Option A or B

Universal RotoBolt **UR40•20** Instructions - *Basic Board* PATENT PENDING



Certification Upgrade to **UR20•20**

Works With:



**Premier
PI20•Nx**



**Premier II
PI80•Nx**



**THinPut
TH20•D6**




**EasyTouch
ET20•Nx**



**QuickTouch
QT20•N3**

Universal RotoBolt Dimensions (Imperial)



UL Type 1
VdS EN1300 Class B



QSecurityProducts.com

1014 S. Main Street • Nicholasville, Kentucky 40356 • **859.241.2063**

Universal RotoBolt UR40•20 INSTRUCTIONS • Rev. 2412 • © 2024 QSecurity Industries



FEATURES

The UR40•20 features a user-changeable 6-digit Primary code which can be used to activate or delete a Secondary user code. Entering a valid code starts a 3 second window for unlocking, allowing movement of the safe boltwork into the OPEN position. The RotoBolt automatically secures after moving the safe boltwork to the fully LOCKED position.

MOUNTING INSTRUCTIONS

The UR40•20 may be mounted either RH, LH, VU or VD or it may be flipped over to block a reversed boltwork design. Insert the connector from the keypad into the lock receiver. Ensure that the connector is fully seated. To remove the connector, carefully lift and pull away from the lock body.

Use only the supplied 1/4-20 (or M6) screws to mount the lock. Tighten the screws securely so the lock body is firmly attached to the flat mounting surface. Use of screw locking glue (i.e. LocTite) is recommended. Secure cables away from moving parts.

ELECTRONICS TEST

Like all NL Locks, the RotoBolt includes Function 5 - a unique feature to test for proper functioning of the electronics:


- Press and hold 5 until double beep and keypad LED stays on, then release
- Enter all keys in numerical sequence: 1-2-3-4-5-6-7-8-9-0
- A double beep at each key press indicates that the lock and keypad are communicating and performing properly
- A long signal indicates a fault that can likely be corrected by replacing the keypad

FUNCTIONAL TEST (With door OPEN)

Enter code (factory code = 5-5-5-5-5-5), double beep indicates valid entry

- Turn boltwork handle to OPEN position
- The bolt rotates into the lock housing
- The bolt must move freely
- Turn boltwork handle to the LOCKED position
- The bolt must fully extend and secure
- Ensure that there is a minimum of 1/16" clearance on all sides of the lock bolt when the safe boltwork is in the fully LOCKED position

IMPORTANT: Repeat the functional test several times before locking the safe door!



BOLTWORK REQUIREMENTS

If the Rotobolt lock is used in conjunction with another lock, the boltwork must be constructed so that the Rotobolt secures first.

In the LOCKED position, the distance between the Rotobolt lock bolt and the movable boltwork must be a minimum of 1/16" (1.5mm).

UL Type 1
VdS EN1300 Class B





OPERATION

Enter code (factory code = 5-5-5-5-5-5), double beep indicates valid entry

Turn boltwork handle to the OPEN position

If not opened within 3 seconds, the lock re-secures automatically

If the first code entry fails, wait 10 seconds before re-entering

If 10 seconds elapse without a key press, the code entry will be cancelled.

Locking / Status:

Close door and rotate handle to fully locked position

Verify locked/secure status by attempting to rotate handle

Manipulation Protection:

Upon entry of four consecutive invalid codes, the keypad is blocked and will not accept entries for 5 minutes. During this period, the LED flashes every 10 seconds and any key press causes a long beep. Upon expiration, the entry of two more invalid codes restarts the 5 minute blocking period.

NOTE: A series of beeps following code entry indicates a weak battery that must be replaced

Use ONLY Energizer™ or Duracell™ 9V ALKALINE batteries

ACTIVATE THE LOCK (One-time process)

Press and hold "0" key until double beep and keypad LED stays on, then release

- Enter 1-2-3-4-5-6 as Primary code (double beep)
- Re-enter 1-2-3-4-5-6 to confirm (double beep and LED goes out)

INSTALL/CHANGE PRIMARY USER CODE

Press and hold "0" key until double beep and keypad LED stays on, then release

- Enter Primary code (now 1-2-3-4-5-6), double beep confirms valid entry
- Enter new 6-digit or 6-letter code, double beep
- Re-enter new 6-digit or 6-letter code to confirm (double beep and LED goes out)
- **Test the new Primary code and rotate safe handle several times before closing the door**
- See below to set a Secondary user code and/or Page 3 if you require Time Delay

INSTALL/CHANGE SECONDARY USER CODE

Press and hold "1" key until double beep and keypad LED stays on, then release

- Enter existing 6-digit Primary code, double beep
- Enter new Secondary code, double beep (do NOT enter 1-2-3-4-5-6 as Secondary code)
- Confirm the Secondary code, double beep and LED goes out
- The 6-digit Secondary code is now active and can open the lock

NOTE: The Primary code is required to delete the Secondary code.

The Primary code can be changed, but cannot be deleted.

DELETE SECONDARY USER CODE

Press and hold "3" key until double beep and keypad LED stays on, then release

The LED remains on during the following actions:

- Enter Primary code, double beep
- The Secondary code is deleted and only the Primary code can open the lock (Single User)

FACTORY RESET

Press and hold "0" key until double beep and keypad LED stays on, then release

- Enter current Primary code, double beep
- Enter 5-5-5-5-5-5, double beep
- Re-enter 5-5-5-5-5-5, double beep indicates successful operation



PROGRAMMING TIME DELAY • INITIAL SET-UP

Delay Range: 0-99 minutes

Open Window Range: 1-19 minutes

Press and Hold "9" key until double beep and keypad LED stays on, then release

The LED remains on during the following actions:

- Enter six-digit Primary code, double beep
- Enter delay then open window times in two-digit values, double beep.
For Example: to program a 26 minute delay and 12 minute open window, enter: "2612"
- Re-enter new delay and open window times to confirm
(double beep indicates valid operation and LED will go out)

NOTE: A long beep following any entry indicates an invalid or out of range entry.

OPEN WITH TIME DELAY ACTIVATED

Enter valid six-digit code: ex. 5-5-5-5-5-5 (factory code)

Beep and LED flash at each key press

If code is valid, double beep at last digit

Time delay counting starts, LED flashes every 2 seconds

When delay period elapses, open window period begins, indicated by LED flashes and beep sounds every 1 second

- Re-enter valid six-digit code
- If code is valid, double beep at last digit
- Within 3 seconds, turn handle to the OPEN position

CHANGING TIME DELAY VALUES

Begin time delay by entering a valid code

Once the delay period has elapsed and during the open window, press and hold "9" key until the LED remains ON, then release

- Enter the six-digit Primary code, double beep, LED will remain ON
- Enter new delay and open window times in two-digit values, double beep
- Re-enter new delay and open window times to confirm
(double beep indicates valid operation and LED will go out)

NOTE: To cancel/remove time delay, enter "0001" during the open window

Decreasing the time delay period may be done only during the open window period



To view our full line of
products, Warranty and
other Instruction Manuals

